


Interfacing of MQ-4 [Methane Sensor]





MQ-4 [Methane Sensor]

- The MQ4 is used in gas leakage detecting equipment in consumer and industry markets, this sensor is suitable for detecting CH4, Natural gas, LNG, avoid exposure to alcohol, cooking fumes, and cigarette smoke. The sensitivity can be adjusted by the potentiometer.
- As a natural gas sensor, the MQ-4 Natural Gas Sensor is a fast and reliable sensor with a high sensitivity to natural gas and methane, also good sensitivity to propane and butane.




Components Required

- Arduino UNO
- MQ-4 Methane Sensor
- LED
- Jumper Wires



Connection Diagram





Connections

- Connect Vcc of MQ-4 with +5 V of Arduino UNO.
- Connect **DOUT** of MQ-4 with pin 8 of Arduino UNO.
- Connect AOUT of MQ-4 with A0 of Arduino UNO.
- Connect GND of MQ-4 with GND of Arduino UNO.
- Connect positive pin of LED with pin 13 of Arduino UNO and LED's negative with GND of Arduino UNO.

1 = GND
2 = DOUT
3 = AOUT
4 = Vcc
(bottom view)



After uploading done

- Open Serial Window at the upper-right hand corner of the Arduino IDE, when no gas is detected, the sensor will export 1(high voltage) to the serial monitor and the LED will be turned on.
- When gas generated by the lighter nears the sensor, it will export
 0 (low voltage) and the LED will turn off.



Project Link: