

Interfacing of Color Sensor





TCS230 TCS3200 Color Sensor

- The TCS230 senses color light with the help of an 8 x 8 array of photodiodes.
- The color sensor detects the color of the surface, usually in the RGB scale. Color is the result of interaction between a light source, an object and an observer.
- In case of reflected light, light falling on an object will be reflected or absorbed depending on surface characteristics, such as reflectance and transmittance.




Components Required

- Arduino UNO
- TCS230 TCS3200 Color Sensor
- Jumper Wires



Connection Diagram





Connections

- Connect **SO** pin of color sensor with pin **8** of Arduino .
- Connect **S1** pin of color sensor with pin **9** of Arduino .
- Connect **OUT** pin of color sensor with pin **10** of Arduino .
- Connect **S2** pin of color sensor with pin **12** of Arduino .
- Connect S3 pin of color sensor with pin 11 of Arduino.
- Connect DE & GND pin of color sensor with GND of Arduino.
- Connect **Vcc** pin of color sensor with **+5V** of Arduino .



Project Link: